

RS-ST PRO Programmable Setup Sheet



INFORMATION

Driver : **Hayato Matsuzaki** Date/ 日時 : ____ / ____ / ____ Circuit name/ サーキット名 : _____

※Basic settings

Track Size : ☐ Large ☐ Medium ☐ Small Surface/ 路面 : ☐ Asphalt ☐ P-Tiles ☐ Carpet ☐ Others _____

Chassis/ シャーシ : **Rêve D RDX** Motor : **Absolute1 13.5T** Timing Advance/ 進角 : _____

Gyro : **REVOX** Curve : _____ Gain : _____ Servo Horn : _____ Pinion Gear : _____ Spur Gear : _____ Tire : _____

SETUP DATA

TRANSMITTER : ☐ Basic mode ☐ Futaba mode ☐ Sanwa mode

SERVO TRIM : ☐ Left ☐ Right **0** (-20 ~ 0 ~ 20)

TORQUE : **14** (1~35) DAMPER : **210** (1~600) MAX POWER : **60** (1~120)

INTL TORQUE : **22** (1~60) DAMPER POINT : **44** (1~200) FREQUENCY : **5** (1~7)

MID-TORQUE : **38** (1~60) SPEED CURVE : **103** (1~200) DEAD BAND : **4** (1~20)

MAX-TORQUE : **10** (1~60) COUNTER ASSIST : **28** (1~50) DIRECTION : ☐ CW ☒ CCW

TORQUE CURVE : **230** (1~250)

Note

• Sanwa M17S

CLS MOTOR
RS-ST PRO